





CALIBRATE KITCHEN OVEN

	A	B	C	D	E	F	G	H	I	J	K	L
1	<b>CALIBRATION OF KITCHEN OVEN</b>											
2		F. GADEK		11/6/2004								
3	DATE ->	<b>11/2/2004</b>		<b>XX/XX/2004</b>		<b>11/8/2004</b>		<b>11/13/2004</b>				<b>DIF</b>
4	<b>DIAL</b>	<b>OLD</b>	<b>NEW</b>	<b>OLD</b>	<b>NEW</b>	<b>OLD</b>	<b>NEW</b>	<b>OLD</b>	<b>NEW #2</b>	<b>NEW #3</b>	<b>OVERALL</b>	<b>AVG T -</b>
5	<b>SETTING</b>	<b>THERM</b>	<b>THERM</b>	<b>THERM</b>	<b>THERM</b>	<b>THERM</b>	<b>THERM</b>	<b>THERM</b>	<b>THERM</b>	<b>THERM</b>	<b>AVERAGE</b>	<b>SETTING</b>
6												
7	WARM	175	152		140		150		140	125	147	
8	200	190	215	100	190	175	200	185	200	175	181	<b>-19</b>
9	225					217	248	225	232	200	224	-1
10	250	250	262	230	275	230	275	250	262	230	252	2
11	275					252	292	275	290	250	272	-3
12	300	275	290	275	335	265	305	300	320	275	293	-7
13	325			320	355	280	320	325	340	300	320	-5
14	<b>350</b>	315	<b>350</b>	325	365	325	348	335	352	315	337	<b>-13</b>
15	<b>375</b>					349	375	358	380	348	362	<b>-13</b>
16	<b>400</b>	325	<b>400</b>			325	398	377	390	370	369	<b>-31</b>
17	<b>425</b>					380	430	383	418	400	402	<b>-23</b>
18	450	415	445			395	440	405	418	415	419	<b>-31</b>
19	475					420	460	435	460	455	446	<b>-29</b>
20	<b>500</b>	452	<b>500</b>			428	468	455	460	435	457	<b>-43</b>
21	<b>525</b>					450	500	470	480	480	476	<b>-49</b>
22	550											
23												
24	<b>NOTES:</b>											
25		[1] NEW THERMOMETER ONLY GOES TO <b>500</b>										
26		[2] OLD AND NEW THERMOMETERS PLACED										
27		LEFT AND RIGHT RESPECTIVELY AS FAR TO EDGE										
28		AS POSSIBLE BUT NOT TOUCHING EDGE OF OVEN										
29		ON TOP SHELF SET AT HIGHEST LEVEL.										
30		[3] WAITED UNTIL ORANGE LIGHT WENT OFF TO										
31		INDICATE OVEN FINISHED HEATING										
32		[4] 2 RECTANGULAR BAKING STONES IN OVEN										
33		ONE AT BOTTOM SHELF AND ONE AT TOP SHELF										
34		THEY ARE "HEAT SINKS" AND STABILIZE										
35		ANY TEMPERATURE FLUCTUATIONS										